


User Manual



Floox chargers user manual

CONTENTS

Introduction.....	2
1. Basic user interface	3
2. Network configuration	4
2.1 Connect to wired network	4
2.2 Connect to wireless network	7
2.3 SIM configuration	11
2.4 Check connection	15
3. Operating process	16
3.1 Configuration of the charger	18
3.2 Charger status	20
3.3 Charger operation	21
4. Status codes	24

Introduction


The aim of this document is to outline the implementation process and the main commands. Please complete the INSTALLATION MANUAL document in this manner.



Warning! Do not use an extension cable set or a second set of cables in addition to the cable set for connecting the electric vehicle to the charger.

Only adapters approved by the vehicle manufacturer should be used.

1. Flood charger


**Note:**

In accordance with the requirements of EN-17186, this document establishes harmonised identifiers for electric road vehicle power supplies. The requirements of this standard are intended to complement the information needs of users in terms of compatibility between EV charging stations, cable assemblies and vehicles on the market. The identifier is intended to be displayed on charging stations, vehicles, wiring harnesses, electric vehicle dealers and user manuals as described above (for the CE model).

2. Network Configuration

2.1 Connect to a wired network

The following section explains how to connect the Lyra 60-80 charger to your wired network.



Step 1

In order to configure the wired (WAN) gateway, you must first access the Router configuration. Note the orientation of the Router and locate the connections marked "LAN1" to "LAN4" at the bottom. Connect an RJ45 cable between your PC and the Router to any of the available LAN ports.

Step 2

Your Router is configured within the 192.168.0.x subnet. Configure your PC to access the Router using the following settings:

IP: 192.168.0.101*
Mask: 255.255.255.0
Gateway: 192.168.0.1


**Do not use 192.168.0.1, 192.168.0.100. If your Router has DHCP enabled, it will assign one automatically.*



IMPORTANT: Restart your PC's network connection if necessary for the changes to take effect.


The following section explains how to connect the Lyra 60-80 charger to your wired network. Please enter the following details to access it:

Username: adm
Password: 123456



Step 3

Note the orientation of the Router and locate the WAN connector on the bottom. That connector is silkscreened "WAN" and adjacent to the Ethernet LAN inputs. Connect the cable to your internal network here.




Step 4

Configure the WAN connection according to the characteristics of your organisation. Access the "Network > WAN" submenu to configure the connection parameters.

If you want to use dynamic IPs assigned by your own network, enable the "DHCP" option in the "Type" field and click "Apply". You can change the Router's MAC if necessary in the "MAC Address" field.

Check with your network manager to confirm that you can use such a configuration.



If you want to use a static configuration, select the "Static IP" option in the "Type" field. Next, configure the "IP Address", "Netmask" and "Gateway" parameters according to your network configuration and click "Apply". You can change the Router's MAC if necessary in the "MAC Address" field.

Check with your network manager to confirm that you can use such a configuration.

		WAN	
Type	Static IP		
Shared Connection(NAT)	<input checked="" type="checkbox"/>		
Default Route	<input checked="" type="checkbox"/>		
MAC Address	00:18:05:2C:61:FB	Default	Clone
IP Address	10.10.1.13		
Netmask	255.255.255.0		
Gateway	10.10.1.1		
MTU	Default	1500	

Step 5

Now configure your LAN network. To do this, go to "Service / DHCP Service" and activate the DHCP service. Since the IP 192.168.0.100 is reserved for the charger application, within the range of IPs, choose between 192.168.0.101 and 254 so that any other element connecting to the LAN port will have an IP within that range.

		DHCP Service	
Enable DHCP	<input checked="" type="checkbox"/>		
IP Pool Starting Address	192.168.0.101		
IP Pool Ending Address	192.168.0.254		
Lease	60	Minutes	
DNS	192.168.0.1 Edit		
Windows Name Server (WINS)	0.0.0.0		
Domain Option	<input type="checkbox"/>		

If you need to set the IPs of any of your devices, add them in the "Static DHCP" field in the same section. Fill in the "MAC Address", "IP Address" and "Host" fields and click "Add".

Lastly, click on "Apply" to apply the changes.

Static DHCP			
MAC Address	IP Address	Host	
00:01:02:33:44:55	192.168.0.25	cdmBk25	Add

[Apply](#) [Cancel](#)

2.2 Connect to wireless network

The following section explains how to connect the Lyra 60-80 charger to your wireless network.

Step 1

Your Router is configured within the 192.168.0.x subnet. Configure your PC to access the Router using the following settings:

IP: 192.168.0.101*
Mask: 255.255.255.0
Gateway: 192.168.0.1

**Do not use 192.168.0.1, 192.168.0.100. If your Router has DHCP enabled, it will assign one automatically.*



IMPORTANT: Restart your PC's network connection if necessary for the changes to take effect.

Step 2

From your usual browser access the IP 192.168.0.1 and you will see the Router login screen. Please enter the following details to access it:

Username: adm
Password: 123456



Step 3

In order to connect the Router to an existing Wi-Fi network you must change the operating mode from "AP" to "STA". To do this, go to the menu "Network > Switch WLAN Mode". Under "WLAN Type" select the "STA" option and click "Apply". The Router will save the changes.

Switch WLAN Mode

WLAN Type: STA *Reboot to take effect)

Apply Cancel

Step 4

The Router must be rebooted in order to change the WLAN mode after the configuration has been changed. To do this, go to "System > Reboot". In the popup that appears, select "OK". After a few seconds, the Router will restart automatically. Wait until the process has been completed.

Step 5

WLAN Client

Enable:

Mode: 802.11b/g/n

SSID: FlooxTestWifi Scan

Auth Mode: WPA2-PSK

Encryption Method: AES

WPA/WPA2 PSK: *****

Apply Cancel

Check that the "WLAN Client" option appears in the "Network" menu. Select it to access the WLAN Client submenu. Make sure that the "Enable" option is selected. In the SSID section click on "Scan". You will then be presented with a list of the different Wi-Fi networks available in your environment.

WLAN Client							
Channel	SSID	BSSID	Security	Signal(%)	Mode	Select AP	
1	Premium	26:81:b4:af:bd:0e	WPA2PSK/AES	31	11b/g/n	Connect	
8	Floox_chargers1	5c:a6:e6:76:5c:86	WPA2PSK/AES	2	11b/g/n	Connect	
8	Floox_chargers1	5c:a6:e6:76:5b:fa	WPA2PSK/AES	83	11b/g/n	Connect	
11	premium_int	22:81:b4:af:bb:f8	WPA2PSK/AES	10	11b/g/n	Connect	
11	Premium_ev	1c:81:b4:af:bb:f8	WPA1PSK/WPA2PSK/AES	10	11b/g/n	Connect	
11	premium_int	22:81:b4:af:bb:72	WPA2PSK/AES	100	11b/g/n	Connect	
11	Premium_ev	1c:81:b4:af:bb:72	WPA1PSK/WPA2PSK/AES	100	11b/g/n	Connect	

Back Refresh

Step 6

Select the Wi-Fi option you want to connect to and click on "Connect"

WLAN Client

Enable	<input checked="" type="checkbox"/>
Mode	802.11b/g/n ▼
SSID	premium_int Scan
Auth Mode	WPA2-PSK ▼
Encryption Method	AES ▼
WPA/WPA2 PSK	*****

Enter the network password and click "Apply". The Router will connect to the desired Wi-Fi. If you check the list of networks, it should appear as "Connected".



IMPORTANT: Check that you can meet the requirements for the Wi-Fi network to which you need to connect. Pay special attention to the password, authentication mode and encryption. If you cannot connect, first check if you meet the minimum requirements. Consult your network manager for more details.

Step 7

Now configure your LAN network. To do this, go to "Service / DHCP Service" and activate the DHCP service. Since the IP 192.168.0.100 is reserved for the charger application, within the range of IPs, choose between 192.168.0.101 and 254 so that any other element connecting to the LAN port will have an IP within that range.

DHCP Service

Enable DHCP	<input checked="" type="checkbox"/>
IP Pool Starting Address	192.168.0.101
IP Pool Ending Address	192.168.0.254
Lease	60 Minutes
DNS	192.168.0.1 Edit
Windows Name Server (WINS)	0.0.0.0
Domain Option	<input type="checkbox"/>

Static DHCP

MAC Address	IP Address	Host
00:01:02:33:44:55	192.168.0.25	ccimx8x25

If you need to set the IPs of any of your devices, add them in the "Static DHCP" field in the same section. Fill in the "MAC Address", "IP Address" and "Host" fields and click "Add".



The screenshot shows a web interface for configuring Static DHCP. At the top, there is a header "Static DHCP". Below it is a table with three columns: "MAC Address", "IP Address", and "Host". The table contains one row with the following values: "00:01:02:33:44:55", "192.168.0.25", and "cdm@k25". To the right of the table is an "Add" button. Below the table are "Apply" and "Cancel" buttons.

MAC Address	IP Address	Host
00:01:02:33:44:55	192.168.0.25	cdm@k25


Apply Cancel

Lastly, click on "Apply" to apply the changes.

2.3 SIM configuration

Step 1

Note the orientation of the Router and locate the SIM slot on the top of the Router. This is marked "SIM1 / SIM2" and is located adjacent to the power and expansion cable.



Step 2

We recommend disconnecting the Router from the power supply before proceeding to install the SIM. Disconnect the power connector before removing the SIM tray.

Step 3

Remove the tray by pressing a thin rod or paper clip into the recess on the side of the tray (see the blue arrow in the picture).

Step 4

The SIM tray has space for two standard SIM cards. If using a SIM, insert it in the SIM1 position by orienting it correctly according to the notch in the SIM holder. If you wish to use two SIMs in your system, follow the same process with your other SIM in the second slot.

By default the Router uses the network determined by SIM1 as the preferred network. If you use two SIMs, place your preferred network in the SIM1 position and your secondary network in SIM2.

Note the orientation of the Router and locate the SIM slot on the top of the Router. This is marked "SIM1 / SIM2" and is located adjacent to the power and expansion cable.




Note: Note the orientation of the SIM tray when inserting it back into the Router. Do not force it if it does not fit. Make sure that it is oriented correctly and that the base is free of objects and/or dirt. Check that the SIM(s) are properly positioned in the tray.

Step 5

Re-power the Router by connecting the cable you removed in Step 2. Wait a few seconds for the Router to reboot and start up.

Step 6

In order to configure the Mobile gateway you must access the Router configuration. Connect an RJ45 cable between your PC and the Router to any of the available LAN ports (LAN1 to LAN4).



Step 7

Your Router is configured within the 192.168.0.x subnet. Configure your PC to access the Router using the following settings on your PC:

IP: 192.168.0.101*

Mask: 255.255.255.0

Gateway: 192.168.0.1

**Do not use 192.168.0.1, 192.168.0.100. If your Router has DHCP enabled, it will assign one automatically.*




Restart your PC's network connection if necessary for the changes to take effect.

Step 8

From your usual browser access the IP 192.168.0.1 and you will see the Router login screen. Please enter the following details to access it:

Username: adm

Password: 123456



Step 9

Access the submenu "Network > Dial Interface / Cellular" to configure the connection parameters.

Step 10

Within the "Profiles" menu, define the configuration that your SIM will use and click on "Add".

- APN
- Access Number
- Authentication Type

Your telecommunications provider should have provided you with the required configuration data; add them according to your premises.

Profiles

Index	APN	Access Number	Authentication Type
1	networkwap.es	*99#	Auto

Step 11

Under "SIM1 Network Provider" choose the profile you have just created.

Step 12

Check the "Show Advanced Options" option to display the advanced options. Locate the "PIN Code" field and enter your SIM PIN. Keep the rest of the default options. Your equipment will use this network to connect to your mobile network coverage.

SIM1 Network Provider: Profiles 1 [Manage](#)

Network Select Type: Auto

Connection Mode: Always Online

Redial Interval: 30 Seconds

Show Advanced Options

Dual SIM Enable:

Initial Commands: AT

Binding ICCID:

PIN Code:

MTU: 1500

Step 13

Click on "Apply" to save the settings.

OPTIONAL: If you are using two SIMs, follow the steps below.



Step 14

Enable the "Dual SIM Enable" option. New options will appear in the menu.



Step 15

Define a new communications profile for it in the same way as described in Step 10, but with your second SIM.

Step 16

Locate the "SIM2 Network provider" field and select the profile you have just created.

Step 17

Locate the "SIM2 PIN Code" field and enter the SIM2 PIN.

Step 18

Go to the "Main SIM" field and select your preferred SIM. By default the Router uses SIM1 as the preferred SIM. Select SIM2 if you prefer to use this as a favourite. Keep the rest of the default options.

Step 19

Click on "Apply" to save the settings.

Step 20

Now configure your LAN network. To do this, go to "Service / DHCP Service" and activate the DHCP service. Since the IP 192.168.0.100 is reserved for the charger application, within the range of IPs, choose between 192.168.0.101 and 254 so that any other element connecting to the LAN port will have an IP within that range.

DHCP Service

Enable DHCP

IP Pool Starting Address

IP Pool Ending Address

Lease Minutes

DNS [Edit](#)

Windows Name Server (WINS)

Domain Option

If you need to set the IPs of any of your devices, add them in the "Static DHCP" field in the same section. Fill in the "MAC Address", "IP Address" and "Host" fields and click "Add".

Static DHCP

MAC Address	IP Address	Host
00:01:02:33:44:55	192.168.0.25	qimwbx25

[Add](#)

[Apply](#) [Cancel](#)

Lastly, click on "Apply" to apply the changes.

2.4 Check Internet connection

If you want to check that you have a external connection, the easiest way to do this is to use the PING command. Go to the Router's "Tools > PING" menu, fill in the "Host" field with a known Web or IP of your target network and press the "Ping" button.

In this example the charger allows access to the Internet, you can ping 8.8.8.8 (Google).

PING

Host [Ping](#)

Ping Count

Packet Size Bytes

Expert Options

```

PING 8.8.8.8 (8.8.8.8): 32 data bytes
40 bytes from 8.8.8.8: seq=0 ttl=113 time=12.792 ms
40 bytes from 8.8.8.8: seq=1 ttl=113 time=11.494 ms
40 bytes from 8.8.8.8: seq=2 ttl=113 time=12.133 ms
40 bytes from 8.8.8.8: seq=3 ttl=113 time=11.843 ms

--- 8.8.8.8 ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max = 11.494/12.065/12.792 ms
    
```




Note: In order to test the PING, the destination IP must have ICMP service enabled. Consult your network manager for more details.

3. Operating process

The screen is mainly divided into 3 areas:

- the top one: which allows you to configure and obtain information from the charger,
- the left-hand one: intended for the control of hose 1,
- the right-hand one: intended for the control of hose 2.



Language selection:

The globe icon at the top left allows you to select the language you want to use. Currently you can choose between Spanish, Catalan and English.

Charger information:

The charger information icon will show you relevant information such as SW version, FW and other relevant data.

Network status:

The icon indicates whether your charger is connected to the Internet. If you have not configured the network or are offline it will appear as disabled.

OCPP server status:

The icon indicates the status of the OCPP server. If you have not configured any or it is disconnected, it will appear as disabled.

OCPP server maintenance menu:

This option allows you to make specific settings related to the external OCPP server and connection.

Hose status 1/2:


The colours signify as follows:

- Green: the hose is available,
- Red: the hose is not available,
- Blue: it is charging.

Hose information area 1/2:

From this area you can control the charger and monitor the charging status and any errors. The design of this area depends on the current status of the charger. For more details, please refer to the detailed charger operation section.

The charger also has a day/night mode. Night mode uses dark colour tones, while day mode uses light tones.



3.1 Configuration of the charger


The following section explains how to configure your charger.

Step 1

From your preferred browser, access the IP 192.168.0.100 and enter the following credentials:

User name: adm
Password: floox

Then click on "Submit".



Step 2

Select "Configuration" in the configuration screen; fill in the form fields according to your preferences.

- In the "ChargerBox ID" field enter the identifier of your charger. This information should be provided by your organisation.
- In the "OCPP Server" field, enter the OCPP server to be used. This information should be provided by your organisation.
- In the "Power Limit" field, enter the maximum power you want your charger to provide.

- In the "Payment Required?" field, choose the option that corresponds to your type of installation. The default should be set to "Yes" unless you want to test the charger in-situ.
- In the "User Interface Information" field, enter your organisation's information. This information will appear in the "Information" menu of the charger user.

Step 3

Click on "Save and restart" to save the changes.

Charger Configuration

Power Limit (kW) *

Charger maximum allowed power in Kilowatts

Power Limited by current? *

Yes for setting a current limit. No for disabling current limit

Current Limit (A) *

Charger maximum allowed current in Amperes

Ocpp Server

Ocpp server configuration

ChargeBox ID

Identifier of the charging station

Payment Required? *

Yes for payment required. No for testing with free charges

QR Link

Link that will be obtained when the charger QR is scanned

User Interface information

Informative text that will appear on the user interface info button

SAVE AND RESTART

3.2 Charger status

The following section describes how to obtain the charger status logs.


Step 1

From your preferred browser, access the IP 192.168.0.100 and enter the following credentials:

User name: adm

Password: floox


Then click on "Submit".



Step 2


Select "Status" in the configuration screen; this section shows the current version of the charger and the network connection status.

Go to "Download log files" to get the charger logs. These files contain status information from OCPP and the charger.



3.3 Charger operation

In the following chapter, the user-level operation of the charger is explained in detail. The figure shows the menu diagram for the normal operation of the charger and the flow of screens.



The charger will normally start in states #11 or #1 depending on whether the charge has been pre-reserved (via OCPP) or not; State #0 is an optional state, and allows you to select the language; if there is a problem with any of the hoses, a screen like #14 will be shown, regardless of the prevailing conditions.

For details of each menu, please read the following sections.

#0: Language selection

If you want to change languages, select the globe icon visible at the top left on any screen; a pop-up will show you the languages available for your charger. Choose the language you want to use.

#1: Charger on stand-by

When you start the charger (if you have not pre-booked a charge) you will be shown a screen with the currently available hoses. Each available hose is represented by the charging connector icon, with a green band on the side if it is available.

#2: Card authentication

You will be asked to identify yourself with your card. Place the card on the RFID reader, or Payment Terminal and follow the on-screen instructions.

#3: User verification

Your details will then be verified and a charging session will be enabled.

#4: Hose connection

Connect any of the available hoses to your vehicle. Make sure that the connector and hose are not damaged or dirty.

#5: Synchronisation

The charger will then lock the hose and communicate with your vehicle to set the charging parameters and do its pre-checks. This operation may take a few seconds to complete.

#6: Charge

The charger will start the vehicle charging process automatically. It will indicate the current battery level, the power injected and the elapsed time. The charging time will depend on your battery level and the maximum power allowed by your vehicle. You can stop charging at any time by clicking on "Pause".

#7: User-specified stop

If you have pressed the pause button you will be asked to identify yourself. Place the card on the RFID reader, or Payment Terminal and follow the on-screen instructions.

#8: User verification

Same as #3.

#9: Confirm charging halt

To finish charging, click on "Confirm". If you do not wish to do so, click on "Cancel".

#10: Hose disconnection.

You can now disconnect the hose from your vehicle.

#11: Charge pre-booking.

If you have pre-booked a charge, you will notice that the selected hose will be locked, and a padlock icon will be visible. Select the hose you have reserved.

#12: User verification

Same process as #3.

#13: Hose connection

Connect your vehicle to the hose you have reserved.

#14: Hose not available

The charger can disable one or both hoses depending on station conditions. In the event that either (or both) of them should be disabled, this will be indicated by an unavailability icon, and a red band on the side. Refer to the troubleshooting section or contact Flood Chargers in this case.

4. Status codes

*For the latest status codes, please visit our website.

Codification	Maintenance message (OCPD or Internal communication)	Generic Description
1200100000	Error: Hose 1: DC Relay: Soldered relay	Soldered relay
1200100001	Error: Hose 1: DC Relay: Relay does not close	Relay does not close
2200100000	Error: Hose 2: DC Relay: Soldered relay	Soldered relay
2200100001	Error: Hose 2: DC Relay: Relay does not close	Relay does not close
1200100002	Error: Hose 1: DC Relay: Unexpected disabled signal received	Unexpected disabled signal received
2200100002	Error: Hose 2: DC Relay: Unexpected disabled signal received	Unexpected disabled signal received
1200200000	Error: Hose 1: Temperature measurement: OverTemperature	OverTemperature
2200200000	Error: Hose 2: Temperature measurement: OverTemperature	OverTemperature
1200200001	Error: Hose 1: Temperature measurement: UnderTemperature	UnderTemperature
2200200001	Error: Hose 2: Temperature measurement: UnderTemperature	UnderTemperature
1200200002	Error: Hose 1: Temperature measurement: Temperature Mismatch	Temperature Mismatch
2200200002	Error: Hose 2: Temperature measurement: Temperature Mismatch	Temperature Mismatch
1200200003	Error: Hose 1: Temperature measurement: Temperature diagnostic error	Temperature diagnostic error
2200200003	Error: Hose 2: Temperature measurement: Temperature diagnostic error	Temperature diagnostic error
1200200004	Error: Hose 1: Temperature measurement: Hysteresis	Hysteresis
2200200004	Error: Hose 2: Temperature measurement: Hysteresis	Hysteresis
1200300000	Error: Hose 1: HV measurement: Measurement diagnostic error	Measurement diagnostic error
2200300000	Error: Hose 2: HV measurement: Measurement diagnostic error	Measurement diagnostic error
1200400000	Error: Hose 1: IMD: Positive insulation	Positive insulation
2200400000	Error: Hose 2: IMD: Positive insulation	Positive insulation
1200400001	Error: Hose 1: IMD: Negative insulation	Negative insulation
2200400001	Error: Hose 2: IMD: Negative insulation	Negative insulation
1200400002	Error: Hose 1: IMD: Positive diagnostic error	Positive diagnostic error

Codification	Maintenance message (OCPP or Internal communication)	Generic Description
2200400002	Error: Hose 2: IMD: Positive diagnostic error	Positive diagnostic error
1200400003	Error: Hose 1: IMD: Negative diagnostic error	Negative diagnostic error
2200400003	Error: Hose 2: IMD: Negative diagnostic error	Negative diagnostic error
1200400004	Error: Hose 1: IMD: Runcheck Timeout	Runcheck Timeout
2200400004	Error: Hose 2: IMD: Runcheck Timeout	Runcheck Timeout
1200500000	Error: Hose 1: Hose: Invalid state	Invalid state
2200500000	Error: Hose 2: Hose: Invalid state	Invalid state
1200500001	Error: Hose 1: Hose: Wrong transition	Wrong transition
2200500001	Error: Hose 2: Hose: Wrong transition	Wrong transition
1200500002	Error: Hose 1: Hose: State Timeout	State Timeout
2200500002	Error: Hose 2: Hose: State Timeout	State Timeout
1200500003	Error: Hose 1: Hose: Cable check error	Cable check error
2200500003	Error: Hose 2: Hose: Cable check error	Cable check error
200600000	Error: Charger: Supervisor: Heartbeat error	Heartbeat error
200600001	Error: Charger: Supervisor: Communications error	Communications error
200600002	Error: Charger: Supervisor: Supply undervoltage	Supply undervoltage
200600003	Error: Charger: Supervisor: Clock drift	Clock drift
200600004	Error: Charger: Supervisor: Scheduler failure	Scheduler failure
200600005	Error: Charger: Supervisor: Main loop	Main loop
200600006	Error: Charger: Supervisor: Other safety failure	Other safety failure
200600007	Error: Charger: Supervisor: GPIO Feedback	GPIO Feedback
200600008	Error: Charger: Supervisor: ADC Reference	ADC Reference
200600009	Error: Charger: Supervisor: CP Voltage Measurement	CP Voltage Measurement
200600010	Error: Charger: Supervisor: Stack Guard	Stack Guard
1200700000	Error: Hose 1: Power rail: Power device input fuse error	Power device input fuse error
2200700000	Error: Hose 2: Power rail: Power device input fuse error	Power device input fuse error
1200700001	Error: Hose 1: Power rail: Power device overtemperature	Power device overtemperature
2200700001	Error: Hose 2: Power rail: Power device overtemperature	Power device overtemperature
1200700002	Error: Hose 1: Power rail: Power device AC input failure	Power device AC input failure

Codification	Maintenance message (OCP or Internal communication)	Generic Description
1200700002	Error: Hose 2: Power rail: Power device AC input failure	Power device AC input failure
1200700003	Error: Hose 1: Power rail: PFC voltage error	PFC voltage error
1200700003	Error: Hose 2: Power rail: PFC voltage error	PFC voltage error
1200700004	Error: Hose 1: Power rail: Overvoltage shutdown	Overvoltage shutdown
1200700004	Error: Hose 2: Power rail: Overvoltage shutdown	Overvoltage shutdown
1200700005	Error: Hose 1: Power rail: Undervoltage	Undervoltage
1200700005	Error: Hose 2: Power rail: Undervoltage	Undervoltage
1200700006	Error: Hose 1: Power rail: Power rail undertemperature	Power rail undertemperature
1200700006	Error: Hose 2: Power rail: Power rail undertemperature	Power rail undertemperature
1200700007	Error: Hose 1: Power rail: Internal error	Internal error
1200700007	Error: Hose 2: Power rail: Internal error	Internal error
1200700008	Error: Hose 1: Power rail: Unbalanced output voltage	Unbalanced output voltage
1200700008	Error: Hose 2: Power rail: Unbalanced output voltage	Unbalanced output voltage
1200700009	Error: Hose 1: Power rail: Generic Failure	Generic Failure
1200700009	Error: Hose 2: Power rail: Generic Failure	Generic Failure
1200700010	Error: Hose 1: Power rail: HILO mode not applied	HILO mode not applied
1200700011	Error: Hose 1: Power rail: Output voltage below limit	Output voltage below limit
1200700012	Error: Hose 1: Power rail: Not turned on	Not turned on
1200700013	Error: Hose 1: Power rail: DCDC EPROM Failure	DCDC EPROM Failure
1200700014	Error: Hose 1: Power rail: Bleeder Failure	Bleeder Failure
1200800000	Error: Hose 1: Power rail HW: Output overcurrent	Output overcurrent
1200800001	Error: Hose 1: Power rail HW: AC imbalance	AC imbalance
1200800002	Error: Hose 1: Power rail HW: AC open phase	AC open phase
1200800003	Error: Hose 1: Power rail HW: Cabling Error	Cabling Error
1200800004	Error: Hose 1: Power rail HW: Output Capacitor Voltage Imbalance	Output Capacitor Voltage Imbalance
1200800005	Error: Hose 1: Power rail HW: HWAddress Conflict	HWAddress Conflict
1200800006	Error: Hose 1: Power rail HW: HWAddress Error	HWAddress Error

Codification	Maintenance message (OCPD or Internal communication)	Generic Description
1200800007	Error: Hose 1: Power rail HW: Discharge Circuit Abnormal	Discharge Circuit Abnormal
1200800008	Error: Hose 1: Power rail HW: Low Capacitor Service Life	Low Capacitor Service Life
1200800009	Error: Hose 1: Power rail HW: Clock Sync Error	Clock Sync Error
1200800010	Error: Hose 1: Power rail HW: Short Circuit Lockout	Short Circuit Lockout
1200800011	Error: Hose 1: Power rail HW: Discharge Circuit Error	Discharge Circuit Error
1200800012	Error: Hose 1: Power rail HW: Discharge Circuit Break	Discharge Circuit Break
1200800013	Error: Hose 1: Power rail HW: Discharge Circuit Short	Discharge Circuit Short
1200800014	Error: Hose 1: Power rail HW: Circuit Error Lockout	Circuit Error Lockout
2200700010	Error: Hose 2: Power rail: HILO mode not applied	HILO mode not applied
2200700011	Error: Hose 2: Power rail: Output voltage below limit	Output voltage below limit
2200700012	Error: Hose 2: Power rail: Not turned on	Not turned on
2200700013	Error: Hose 2: Power rail: DCDC EPROM Failure	DCDC EPROM Failure
2200700014	Error: Hose 2: Power rail: Bleeder Failure	Bleeder Failure
2200800000	Error: Hose 2: Power rail HW: Output overcurrent	Output overcurrent
2200800001	Error: Hose 2: Power rail HW: AC imbalance	AC imbalance
2200800002	Error: Hose 2: Power rail HW: AC open phase	AC open phase
2200800003	Error: Hose 2: Power rail HW: Cabling Error	Cabling Error
2200800004	Error: Hose 2: Power rail HW: Output Capacitor Voltage Imbalance	Output Capacitor Voltage Imbalance
2200800005	Error: Hose 2: Power rail HW: HWAddress Conflict	HWAddress Conflict
2200800006	Error: Hose 2: Power rail HW: HWAddress Error	HWAddress Error
2200800007	Error: Hose 2: Power rail HW: Discharge Circuit Abnormal	Discharge Circuit Abnormal
2200800008	Error: Hose 2: Power rail HW: Low Capacitor Service Life	Low Capacitor Service Life
2200800009	Error: Hose 2: Power rail HW: Clock Sync Error	Clock Sync Error
2200800010	Error: Hose 2: Power rail HW: Short Circuit Lockout	Short Circuit Lockout
2200800011	Error: Hose 2: Power rail HW: Discharge Circuit Error	Discharge Circuit Error
2200800012	Error: Hose 2: Power rail HW: Discharge Circuit Break	Discharge Circuit Break

Codification	Maintenance message (OCPP or Internal communication)	Generic Description
2200800013	Error: Hose 2: Power rail HW: Discharge Circuit Short	Discharge Circuit Short
2200800014	Error: Hose 2: Power rail HW: Circuit Error Lockout	Circuit Error Lockout
1200900000	Error: Hose 1: Power rail communication manager: Communications error	Communications error
2200900000	Error: Hose 2: Power rail communication manager: Communications error	Communications error
1200900001	Error: Hose 1: Power rail communication manager: Identification error	Identification error
2200900001	Error: Hose 2: Power rail communication manager: Identification error	Identification error
1201000000	Error: Hose 1: AC relay: Soldered relay	Soldered relay
1201000001	Error: Hose 1: AC relay: Relay does not close	Relay does not close
2201000000	Error: Hose 2: AC relay: Soldered relay	Soldered relay
2201000001	Error: Hose 2: AC relay: Relay does not close	Relay does not close
201100000	Error: Charger: PDM: PDM invalid state	PDM invalid state
201100001	Error: Charger: PDM: PDM wrong transition	PDM wrong transition
201100002	Error: Charger: PDM: PDM state timeout	PDM state timeout
201200000	Error: Charger: Bridge relay: Relay Soldered	Relay Soldered
201200001	Error: Charger: Bridge relay: Relay does not close	Relay does not close
201300000	Error: Charger: Ventilation: Initialization error	Initialization error
201400000	Error: Charger: Internal temperature measurement: Ambient overtemperature	Ambient overtemperature
201400001	Error: Charger: Internal temperature measurement: Ambient undertemperature	Ambient undertemperature
201400002	Error: Charger: Internal temperature measurement: Ambient temperature diagnostics	Ambient temperature diagnostics
201500000	Error: Charger: System configuration: Invalid system configuration	Invalid system configuration
201500001	Error: Charger: System configuration: No configuration	No configuration
201600000	Error: Charger: Charger controller: Generic initialization error	Generic initialization error
201600001	Error: Charger: Charger controller: Invalid State	Invalid State
201600002	Error: Charger: Charger controller: Wrong transition	Wrong transition
201600003	Error: Charger: Charger controller: State Timeout	State Timeout

Codification	Maintenance message (OCPP or Internal communication)	Generic Description
1201600000	Error: Hose 1: Charger controller: EV Emergency Stop	EV Emergency Stop
2201600000	Error: Hose 2: Charger controller: EV Emergency Stop	EV Emergency Stop
1201600001	Error: Hose 1: Charger controller: Invalid connection sequence	Invalid connection sequence
2201600001	Error: Hose 2: Charger controller: Invalid connection sequence	Invalid connection sequence
201700000	Error: Charger: Supply generation: Initialization error	Initialization error
1201800000	Error: Hose 1: CCS communications: CP Invalid	CP Invalid
2201800000	Error: Hose 2: CCS communications: CP Invalid	CP Invalid
1201800001	Error: Hose 1: CCS communications: HLC Communications Error	HLC Communications Error
2201800001	Error: Hose 2: CCS communications: HLC Communications Error	HLC Communications Error
1201800002	Error: Hose 1: CCS communications: SLAC data link error	SLAC data link error
2201800002	Error: Hose 2: CCS communications: SLAC data link error	SLAC data link error
201900000	Error: Charger: Emergency button: Initialization error	Initialization error
201900001	Error: Charger: Emergency button: Emergency button/door switch	Emergency button/door switch



COPYRIGHT © 2024

Premium PSU reserves the right to make changes to this product without prior notice.

email | info@floopower.com

website | floopower.com